



(en) Schematic Manual
MAXI-POWER™ 8XR


TABLE OF CONTENTS

Tail Light Harness Schematic (112266)	(1.1)
Linz 6/4 Generator Cord Schematic (126075)	(1.2)
Kubota D1105 Engine Harness Schematic (112776)	(1.3)
20A GFCI, 30A RV, & 30A Twistlock Standard Outlets Schematic (126099)	(1.4)
20A GFCI, 20A & 30A Twistlock Option Outlets Schematic (126241)	(1.5)
MP 8XR Deep Sea Control Harness Schematic (124992)	(1.6)
PacBrake Air Valve Harness Schematic (126508)	(1.7)

Maxi-Power™ 8XR

1.1 - Tail Light Harness Schematic


No Connections



112266


Maxi-Power™ 8XR

1.2 - Linz 6/4 Generator Cord Schematic



126075


1.3 - Kubota D1105 Engine Harness Schematic



112776


Maxi-Power™ 8XR

1.4 - 20A GFCI, 30A RV, & 30A Twistlock Standard Outlets Schematic



126099


1.5 - 20A GFCI, 20A & 30A Twistlock Option Outlets Schematic



126241

Maxi-Power™ 8XR


1.6 - MP 8XR Deep Sea Control Harness Schematic



124992

126099

1.7 - PacBrake Air Valve Harness Schematic



Maxi-Power™ 8XR

Maxi-Power™ 8XR



**1502 West 4th Avenue
Holdrege, NE 68949**

**phone: (308) 995-4495 • toll free: (800) 562-1373
fax: (308) 995-5887**

www.allmand.com